

Basic SkyScreen Setup

1. Setup SkyScreens **5–10 feet** down range.
2. Place **cables on the ground** as much as possible.
3. Make sure the **cables are separate** from each other.
4. Make sure the chronograph unit itself is **NOT** being hit by **muzzle blast**.
5. **Isolate the unit** from the shockwave.
6. Make sure you are using a recently purchased, **fully charged 9V battery**.
7. The BEST conditions are a **bright, overcast day**.
8. On VERY bright blue-sky days, try **canting the sensors over 60 to 90 degrees either left or right**. This will increase the contrast of the bullet to the background.